

## Dispenser Mounting Instructions


### Tape Mounting: Only for smooth, dry surfaces

1. Clean surface where dispenser will be mounted with supplied prep pad. Allow surface to dry for 60 seconds. Note: When mounting on marlite wallboard, use scouring cleanser. Rinse and dry thoroughly.
2. Peel paper off mounting tape and press dispenser firmly into position.
3. Open dispenser. Press firmly on back mounting plate for 30 seconds. For maximum adhesion, let set for 24 hours before loading refill.

### Screw Mounting: For rough surfaces

1. Pierce mounting tape at mounting holes as required. Be sure protective paper remains in place on mounting tape.
2. Using back plate as template, mark and drill center holes using 1/4" (6mm) spiral masonry drill or 1/4" (6mm) wood drill.
3. Install # 10 x 1" (25mm) plugs or anchors into holes, flush against surface.
4. Insert self-tapping Type A screws # 10 x 1" (25mm) into holes in back plate through mounting tape.
5. Tighten screws securely. Be careful not to over tighten.

Mounting Clearance: Allow 4 inches (10cm) at bottom of dispenser



Tape vs. Screws: Dispenser may be mounted with tape (attached to back of dispenser) or screws